

## Data on PLC switch, load meter display

Command	Description
SECT_PLC_SWITCH_NAME(x)	PLC switch name
SECT_PLC_SWITCH_INPUT(x)	PLC switch input signal
SECT_PLC_SWITCH_INPUT_ALL	PLC switch input signal (collective)
SECT_PLC_SWITCH_OUTPUT(x)	PLC switch output signal
SECT_PLC_SWITCH_OUTPUT_ALL	PLC switch output signal (collective)
SECT_LOAD_METER_COMMENT(x)	Road meter comment