

Ethernet parameter

Command	Data type	Description	PS	AX	RW	Range
M_SSEC_UPETHER_ETHERNET	T_CHAR	Start of service	--	--	RW	0,1
M_SSEC_UPETHER_IPADDR	T_STR	IP address	--	--	RW	Alphanumeric characters, symbols
M_SSEC_UPETHER_SUBNET	T_STR	Subnet mask	--	--	RW	Alphanumeric characters, symbols
M_SSEC_UPETHER_GATEWAY	T_STR	Gateway	--	--	RW	Alphanumeric characters, symbols
M_SSEC_UPETHER_PORTNUMBER	T_LONG	Port No.	--	--	RW	0 to 9999
M_SSEC_UPETHER_BEFORE_HOSTADDR	T_STR	Ethernet communication parameter before conversion (Host address)	--	--	RW	Alphanumeric characters, symbols
M_SSEC_UPETHER_HOSTNUMBER	T_LONG	Host's port No.	--	--	RW	0 to 9999
M_SSEC_UPETHER_LOCAL_IPADDR	T_STR	Local IP Address	-	-	RW	0.0.0.0 to 255.255.255.255
M_SSEC_UPETHER_LOCAL_SUBNET	T_STR	Local Subnetmask	-	-	RW	0.0.0.0 to 255.255.255.255
M_SSEC_UPETHER_PC_AUTO_IPADDR	T_CHAR	IP address automatic setting	--	--	RW	0,1
M_SSEC_UPETHER_PC_IPADDR	T_STR	IP address (PC)	--	--	RW	Within 15 letters, numerics in dot notation
M_SSEC_UPETHER_PC_SUBNET	T_STR	Subnet mask (PC)	--	--	RW	Within 15 letters, numerics in dot notation
M_SSEC_UPETHER_PC_GATEWAY	T_STR	Gateway (PC)	--	--	RW	Within 15 letters, numerics in dot notation
M_SSEC_UPETHER_TIMEOUT	T_SHORT	Time-out	--	--	RW	10 to 99
M_SSEC_UPETHER_USE_HOSTNUMBER	T_CHAR	Host No. to use	--	--	RW	1 to 4
M_SSEC_UPETHER_HOST_LOGINNAME(x)	T_STR	User name (Host A to D) (x=0 to 3)	--	--	RW	Within 15 letters
M_SSEC_UPETHER_HOST_PWORD(x)	T_STR	Password (Host A to D) (x=0 to 3)	--	--	RW	Within 15 letters
M_SSEC_UPETHER_HOST_DIRPATH(x)	T_STR	Directory (Host A to D) (x=0 to 3)	--	--	RW	Within 63 letters (M75X: Within 31 letters)
M_SSEC_UPETHER_HOST_IPADDR(x)	T_STR	Host address (Host A to D) (x=0 to 3)	--	--	RW	Within 15 letters
M_SSEC_UPETHER_HOST_TYPE(x)	T_CHAR	Host type (Host 1 to 4) (x=0 to 3)	--	--	RW	0 to 2
M_SSEC_UPETHER_HOST_WORD_FILE(x)	T_SHORT	Host word position: File (Host 1 to 4) (x=0 to 3)	--	--	RW	0 to 100
M_SSEC_UPETHER_HOST_WORD_SIZE(x)	T_SHORT	Host word position: Size (Host 1 to 4) (x=0 to 3)	--	--	RW	0 to 100

M_SSEC_UPETHER_HOST_WORD_DIR(x)	T_SHORT	Host word position: <DIR> (Host 1 to 4) (x=0 to 3)	--	--	RW	0 to 100
M_SSEC_UPETHER_HOST_WORD_CMT(x)	T_SHORT	Host word position: Comment (Host 1 to 4) (x=0 to 3)	--	--	RW	0 to 100
M_SSEC_UPETHER_HOST_WORD_NUM(x)	T_SHORT	Host word number: Comment (Host 1 to 4) (x=0 to 3)	--	--	RW	0 to 100
M_SSEC_UPETHER_HOST_DISP_TYPE(x)	T_CHAR	Host character number (Host 1 to 4) (x=0 to 3)	--	--	RW	0,1