

PLC constant

Command	Data type	Description	PS	AX	RW	Range
M_SSEC_MP_PLC_CONST(x)	T_LONG	PLC constant (x=0 to 95 / [M7] x=0 to 899)	--	--	RW	-99999999 to 99999999